


- As soon as the person suspected of having pinworms wakes up, and before he/she washes, press the adhesive side of a piece of transparent tape (approx. 4 cm) against the skin around the anus, making it adhere well (see Figure A).
- Remove the transparent tape and attach it to the surface of a laboratory slide (can be supplied by the Laboratory) (see Figure B).
- Give the slide to the Laboratory acceptance, transporting it inside a urine culture container if possible.



- A. Apply the adhesive tape around the anus, making sure it adheres well**
- B. Stick the tape onto a laboratory slide.**